

SELECTING HI E OR LO E BASED ON EMISSIVITY TABLE

Metals	Emissivity Range	IRt/c Selection
Aluminum		
highly polished plate, pure	0.04 - 0.06	Lo E
oxidized at 1110 F (600 C)	0.11 - 0.19	Lo E
commercial sheet	0.09	Lo E
Brass		
highly polished plate, pure	0.1	Lo E
oxidized at 1110 F (600 C)	0.61 - 0.59	Lo E
Chromium, polished	0.08 - 0.36	Lo E
Copper		
polished	0.05	Lo E
heated at 1110 F (600 C)	0.57	Lo E
Gold, pure, highly polished	0.02 - 0.03	Lo E
Iron and steel (excluding stainless)		
iron, polished	0.14 - 0.38	Lo E
cast iron, polished	0.21	Lo E
cast iron, oxidized at 1100 F (600 C)	0.64 - 0.78	Lo E
wrought iron, polished	0.28	Lo E
wrought iron, dull oxidized	0.94	Hi E
iron plate, rusted	0.69	Lo E
steel, polished	0.07	Lo E
steel, oxidized at 1110 F (600 C)	0.79	Lo E
rolled sheet steel	0.66	Lo E
steel plate, rough	0.94 - 0.97	Hi E
Lead, gray oxidized	0.28	Lo E
Mercury	0.09 - 0.12	Lo E
Molybdenum filament	0.10 - 0.20	Lo E
Nickel		
polished	0.07	Lo E
plate, oxidized at 1110 F (600 F)	0.37 - 0.48	Lo E
Platinum		
polished plate, pure	0.05 - 0.10	Lo E
wire	0.07 - 0.18	Lo E
Silver, pure, polished	0.02 - 0.03	Lo E
Stainless steel		
polished	0.07	Lo E
type 310, oxidized from furnace service	0.90 - 0.97	Hi E
Tin, bright	0.06	Lo E
Tungsten filament, aged	0.03 - 0.35	Lo E
Zinc		
commercial pure, polished	0.05	Lo E
galvanized sheet	0.21	Lo E

Nonmetals	Emissivity Range	IRt/c Selection
Asbestos	0.93 - 0.94	Hi E
Brick		
red, rough	0.93	Hi E
fire clay	0.75	Hi E
Carbon		
filament	0.53	Hi E
lampblack, rough deposit	0.78 - 0.84	Hi E
Glass (Pyrex, lead, soda)	0.85 - 0.95	Hi E
Marble, light gray, polished	0.93	Hi E
Paints, lacquers, and varnishes		
white enamel	0.91	Hi E
flat black lacquer	0.96 - 0.98	Hi E
aluminum paints	0.27 - 0.67	Lo E
oil paints, 16 colors	0.92 - 0.96	Hi E
Porcelain, glazed	0.92	Hi E
Quartz, opaque	0.68 - 0.92	Hi E
Water	0.95 - 0.96	Hi E
Wood, oak, planed	0.90	Hi E

Note: Lower emissivity surfaces require more stable conditions than high emissivity surfaces for accurate temperature control. These tables include approximate values, which can vary significantly with surface condition. For best results, install an IRt/c and test. Emissivity data from *Heat, Mass, and Momentum Transfer* by Rohsenow and Choi (Prentice-Hall, 1961).

Exergen Corporation office:

USA
400 Pleasant Street
Watertown, MA 02472
Tel: +1 617 923 9900 press 4 for industrial
Fax: +1 617 923 9911

Exergen Industrial International/OEM Sales office:

Clever IR
The Netherlands
Pastoor Clercxstraat 26
5465 RH Veghel
Tel: +31 (0)413 376 599

industrial@exergen.com
www.exergen.com